


Contents	Page
Ramp and door accessories: Hinges, spring bolts, antiluce plates, gas strut and lock rods	75
Ramp and door accessories: Antiluce & linch pin fasteners & receivers, lock mechanisms & handles	76
Self tapping & wood screws, Spirol and locking pins & rivets	77
Engineering grade bolts, nuts & washers in sizes M5-M10	77
Engineering grade bolts, nuts & washers in sizes M12-M16	78
Washers (plated, plain & coloured) plastic spacers & door stops	79
Roofing bolts, coach bolts, J bolts, studding, socket headed & Imperial fasteners	80



Ramp & Door Accessories



both on the chassis and in the ramp itself.




Page **76**

Ifor Williams
Parts

Hardware & Ironmongery

Ramp & Door Accessories



C00216 J Bolt (Metric). M12 - 75mm long (replaced imperial bolt from July 2003).



Ifor Williams

Parts

Hardware & Ironmongery

Assorted Fasteners

SELF-TAPPING SCREWS




ı				11	ion aty
		F1227ZPK	Self tapping screw	Number 8 x 3/8" pozidrive flanged.	100
		F1229ZPK	Self tapping screw.	Number 8 x1/2" pozidrive flanged.	100
2	•	F1241ZPK	Self tapping screw.	Number 12 x 3/4" pozidrive pan head.	50
		F1242ZPK	Self tapping screw.	Number 12 x 1" pozidrive pan headed.	100
		F1252ZPK	Self tapping screw.	Number 14 x 1" pozidrive pan head.	50
		F1260ZPK	Self tapping screw.	Number 14 x 1-1/4" flooring screw.	50
		F1261ZPK	Self tapping screw.	Number 14 x 1-1/2" flooring screw.	50
		F1262ZPK	Self tapping screw.	Number 14 x 1-3/4" flooring screw.	50
		F1258ZPK	Self tapping screw.	Number 14 x 2" pozidrive pan head.	25
		F1265ZPK	Self tapping screw.	Number 14 x 2-1/2" pozidrive countersunk	. 25
		F1201ZPK	Self tapping screw.	M6 x 12 pozidrive pan head.	50
		F1202ZPK	Self tapping screw.	M6 x 16 pozidrive pan head.	50



		rack City
)	F1313ZPK Wood screw #6. 3/4" supa round headed wood screw.	200
	F1316ZPK Wood screw #8. 1" supa round headed wood screw.	200
	F1318ZPK Wood screw #8. 1-1/4" supa countersunk wood screw.	200
	$\textbf{F1320ZPK Wood screw \#8.} \ 1\text{-}1\text{/}4\text{"} \ \text{supa round headed wood screw}.$	150
	F1325ZPK Wood screw #10. 1-1/4" pozi countersunk wood screw.	150
	F1330ZPK Wood screw #10. 3" supa countersunk wood screw.	50
	F1332ZPK Wood screw #10. 2" supa countersunk wood screw.	50

SPIROL & SELLOCK PINS



		Pack Qty
•	F1910ZPK Spirol pin. 30mm long x 4mm diameter.	10
	F1907ZPK Spirol pin. 3/4" long x 3/16" diameter.	10
	F1909SPK Spirol pin. 3/4" long x 1/4" diameter.	10
•	F1906ZPK Spirol pin. 1" long x 3/16" diameter.	10
	F1908ZPK Sellock pin. 2" long x 1/4" diameter.	10



		Pa	ick Oty
D	F0125PK	Maganlok. MGLP – R8 – 6UA (1/4 Bolt).	50
	F0001PK	Rivet. Aluminium Dome head rivet 4.8mm(D) x 9.8mm(L).	50
	F0002PK	Rivet. Aluminium Dome head rivet 4.8mm(D) x 11.4mm(L).	50
	F0003PK	Rivet. Aluminium Dome head rivet 4.8mm(D) x 14.6mm(L).	50
	F0004PK	Rivet. Aluminium Dome head rivet $4.8 \text{mm}(D) \times 17.8 \text{mm}(L)$.	50
8	F0006PK	Rivet. Aluminium Dome head rivet 3.2mm(D) x 5.9mm(L).	50
	F0051PK	Rivet. Aluminium large flange rivet $4.8 mm(D) \times 19.6 mm(L)$.	50
	F0052PK	Rivet. Aluminium large flange rivet $4.8 mm(D) \times 27.5 mm(L)$.	50
	F0053PK	Rivet. Aluminium Dome head rivet 3/16"(D) x 1"(L).	50
0	F0058	Rivet. Steel bulb rivet 4.8mm(D) x 16.5mm(L).	50
	F0070PK	Rivet. Semi-tubular rivet $1/4"(D) \times 1 \cdot 1/4"(L)$ - used in ramp-gate and small cross division construction.	50

HEXAGONAL HIGH TENSILE BOLTS



		Pack Oty
F0302ZPK	M5 Bolt. 25mm long hexagonal headed High Tensile bolt.	20
F0304ZPK	M5 Bolt.~35 mm long hexagonal headed High Tensile bolt.	20
F0310ZPK	$\textbf{M6 Bolt.} \ \textbf{30} \\ \text{mm long hexagonal headed High Tensile bolt.}$	20
F0311ZPK	${\bf M6~Bolt.}~35{\rm mm}$ long hexagonal headed High Tensile bolt.	20
F0315ZPK	$\textbf{M6 Bolt.} \ \textbf{45} \\ \text{mm long hexagonal headed High Tensile bolt.}$	10
F0317ZPK	$\textbf{M6 Bolt.} \ 50 \text{mm long hexagonal headed High Tensile bolt.}$	10
F0318ZPK	${\bf M6~Bolt.}$ 55mm long hexagonal headed High Tensile bolt.	10
F0316ZPK	${\bf M6~Bolt.}$ 65mm long hexagonal headed High Tensile bolt.	10
F0319ZPK	$\textbf{M6 Bolt.} \ \textbf{70} \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\$	10
F0334ZPK	M8 Bolt. 100mm long hexagonal headed black bolt.	10
F0337ZPK	M8 Bolt. 45mm long hexagonal High Tensile bolt.	10
F0328ZPK	$\textbf{M8 Bolt.} \ 40 \text{mm long hexagonal headed High Tensile bolt.}$	10
F0327ZPK	${\bf M8~Bolt.~45} {\rm mm~long~hexagonal~headed~High~Tensile~bolt.}$	10
F0326ZPK	${\bf M8~Bolt.}~{\bf 50} {\bf mm~long~hexagonal~headed~High~Tensile~bolt.}$	10
F0329ZPK	${\bf M8~Bolt.}~{\bf 55} {\bf mm~long~hexagonal~headed~High~Tensile~bolt.}$	10
F0330ZPK	${\bf M8~Bolt.~65} {\rm mm~long~hexagonal~headed~High~Tensile~bolt.}$	10
F0333ZPK	${\bf M8~Bolt.}~70 {\rm mm~long~hexagonal~headed~High~Tensile~bolt.}$	10
F0341ZPK	M10 Bolt. 35mm long hexagonal headed High Tensile bolt	. 10
F0346ZPK	M10 Bolt. 50mm long hexagonal headed High Tensile bolt	. 10
F0349ZPK	M10 Bolt. 65mm long hexagonal headed High Tensile bolt	. 10
F0350ZPK	M10 Bolt. 70mm long hexagonal headed High Tensile bolt	. 10
F0352ZPK	M10 Bolt. 80mm long hexagonal headed High Tensile bolt	. 10

Assorted Fasteners

HEXAGONAL HIGH TENSILE SETSCREWS



	Pack Oty
F0700ZPK M5 Setscrew . 20mm long hexagonal headed High Tensile setscrew.	20
F0701ZPK M6 Setscrew. 12mm long hexagonal headed High Tensile setscrew.	20
F0704ZPK M6 Setscrew. 16mm long hexagonal headed High Tensile setscrew.	20
F0706ZPK M6 Setscrew. 20mm long hexagonal headed High Tensile setscrew.	20
F0707ZPK M6 Setscrew . 25mm long hexagonal headed High Tensile setscrew.	20
F0725ZPK M6 Setscrew . 35mm long hexagonal headed High Tensile setscrew.	20
F0723ZPK M8 Setscrew . 25mm long hexagonal headed High Tensile setscrew.	20
F0732ZPK M10 Setscrew . 16mm long hexagonal headed High Tensile setscrew.	10
F0735ZPK M10 Setscrew . 30mm long hexagonal headed High Tensile setscrew.	10

HEXAGONAL ENGINEERING NUTS



	Pack Oty	
F1001ZPK M5 Nut. Plain hex type.	20	
F1045ZPK M5 Nut. Nyloc type.	20	
F1085ZPK M6 Dome Nut. As used on horsebox trailers, gives a decorative and protective finish.	20	
F1002ZPK M6 Nut. Plain hex type.	20	
F1053ZPK M8 Nut. Indented face provides positive thread locking	g. 20	
F1051ZPK M8 Nut. Nyloc type.	20	
F1008ZPK M10 Locknut. M10 thin locknut.	20	
F1055ZPK M10 Nut. Nyloc type.	20	
F1004ZPK M10 Nut. Plain hex type.	20	



HEXAGONAL HIGH TENSILE BOLTS



	Pack Oty
F0368ZPK M12 Bolt. 40mm long hexagonal headed High Tensile bolt.	10
F0370ZPK M12 Bolt. 50mm long hexagonal headed High Tensile bolt.	10
F0371ZPK M12 Bolt. 60mm long hexagonal headed High Tensile bolt.	10
F0373ZPK M12 Bolt. 65mm long hexagonal headed High Tensile bolt.	10
F0374ZPK M12 Bolt. 80mm long hexagonal headed High Tensile bolt.	10
F0375ZPK M12 Bolt. 90mm long hexagonal headed High Tensile bolt.	10
F0378ZPK M12 Bolt. 100mm long hexagonal headed High Tensile bolt.	10
F0379ZPK M12 Bolt. 110mm long hexagonal headed High Tensile bolt.	10
F0380ZPK M12 Bolt. 120mm long hexagonal headed High Tensile bolt.	4
F0381ZPK M12 Bolt. 130mm long hexagonal headed High Tensile bolt.	4
F0383ZPK M12 Bolt. 150mm long hexagonal headed High Tensile bolt.	4

HEXAGONAL HIGH TENSILE SETSCREWS



	Pack Qty
F0740ZPK M12 Setscrew. 20mm long hexagonal headed High Tensile setscrew.	10
F0741ZPK M12 Setscrew. 25mm long hexagonal headed High Tensile setscrew.	10
F0743ZPK M12 Setscrew. 30mm long hexagonal headed High Tensile setscrew.	10

HEXAGONAL ENGINEERING NUTS



	Pack Oty
F1005SPK M12 Nut. Plain hex type (Self coloured).	10
F1059ZPK M12 Nut. Nyloc type.	10

Assorted Fasteners



	Pack Oty
F1107GPK M8 Washer. M8x21mm plated washer.	20
F1104GPK M10 Washer. M10x24.	20
F1106ZPK M12 Washer. M12x24.	20
F1121ZPK 1/4" Washer. 1/4" x 1/2" plated washer.	20
F1123ZPK 1/4" Washer. 1/4" x 3/4" Light.	20
F1125ZPK 1/4" Washer. 1/4" x 1-1/4" x 1/16".	20
F1146ZPK 1/2" Washer. 1/2" x 1-1/4" x 12 Gauge.	20
F1126ZPK 1/2" Washer. 1/4" x 1-1/2" x 1/16".	20
F1118ZPK 3/16" Washer. 3/16" x 1" plated washer.	20

For the complete selection of coloured bolts and washers please see page 93 for Horseboxes and page 134 for Boxvans



Pack C	lty
--------	-----


	Pa	ack Oty
F1103MAPK	Retainer Washer. This washer sits under the breast bar receiver bolt on the outside of the trailer (red).	16
F1103GRPK	Retainer Washer. This washer sits under the breast bar receiver bolt on the outside of the trailer (green).	16
F1103BLPK	Retainer Washer. This washer sits under the breast bar receiver bolt on the outside of the trailer (blue).	16
F1103WHPK	Retainer Washer. This washer sits under the breast bar receiver bolt on the outside of the trailer (white).	16
F1103SLPK	Retainer Washer. This washer sits under the breast bar receiver bolt on the outside of the trailer (silver).	16
F1103BKPK	Retainer Washer. This washer sits under the breast bar receiver bolt on the outside of the trailer (black).	16
F1103ZPK	Retainer Washer. This washer sits under the breast bar receiver bolt on the outside of the trailer (gold passivated).	16
P1278PK	Neoprene Washer. 40mm washer used under the breastbar retainer washers.	16
F1112ZPK	Neoprene Washer . M8x13mm off-white neoprene washer used on many boxvan fasteners.	16



Ifor Williams

Parts

	Pack Oty
P12810PK Plastic Washer. WASHER (MOSS 32748).	10
P1216PK Nylon Spacer. 3/8" Internal diameter - 3.18mm long.	10
P1220PK Nylon Spacer. 1/4" Internal diameter - 4.76mm long.	10
P1218PK Nylon Spacer. 4.93 Internal diameter- 7.94mm long.	10
P1219PK Nylon Spacer. 1/4" Internal diameter - 11.11mm long.	10
P1217PK Nylon Spacer. 5.16 Internal diameter - 15.88mm long.	10
P1245PK Deck Cleat. Used on the earlier folding deck systems.	10
C74738PK Rampgate bush. The plastic bushes used at the hinge end of P6e ramp or tailboard (2 required).	2
C74737PK Rampgate Spigot. Fitted between the ramp gate and support bracket on some P6e versions.	2



		Pack Qty
F1144ZPK	Antiluce Washer Antiluce Spacer Washer.	10
P1281PK	Poly Washer. Large polythene washer used under linch pin receivers to prevent rattles.	10



P1012M	Door Holder (Male). Used with the female door holder to hold a door open (black).
P1012F	Door Holder (Female). Soft rubber doorstop with centre hole, when used with the male part, can be used to hold a door open (blue).
P1012S	Door Holder (Female). Soft rubber doorstop with centre hole, when used with the male part, can be used to hold a door open (black).
P1014	Doorstop. 1" diameter rubber doorstop (1/2" high).
P1015	Doorstop. 1-1/4" diameter rubber doorstop (7/8" high).



Assorted Fasteners



	Pack Qty
F0505ZPK M6 Roofing bolt. 25mm long slot headed roofing bolt.	20
F0506ZPK M6 Roofing bolt. 30mm long slot headed roofing bolt.	20
F0507ZPK M6 Roofing bolt. 35mm long slot headed roofing bolt.	20
F0508ZPK M6 Roofing bolt. 40mm long slot headed roofing bolt.	20
F0520ZPK M8 Roofing bolt. 30mm long slot headed roofing bolt.	20
F0521ZPK M8 Roofing bolt. 40mm long slot headed roofing bolt.	20
F0602ZPK M6 Cup Square bolt. 20mm long cup square bolt for use in timber panels.	20
F0603ZPK M6 Cup Square bolt . 25mm long cup square bolt for use in timber panels.	20
F0603WPK M6 Cup Square bolt. 25mm long white plastic coated cup square bolt for use on our G.R.P. coated panels.	20
F0605ZPK M6 Cup Square bolt. 30mm long cup square bolt for use in timber panels.	20
F0606ZPK M6 Cup Square bolt. 35mm long cup square bolt for use in timber panels.	20
F0608ZPK M6 Cup Square bolt. 45mm long cup square bolt for use in timber panels.	20
F0611ZPK M6 Cup Square bolt. 60mm long cup square bolt for use in timber panels.	20

For spare wheel fasteners please see page 48



	Pack Oty
F0910ZPK M6 Socket screw. 25mm long Button head.	10
F0906ZPK M6 Socket screw. 30mm long Countersunk head.	10
F0922ZPK M8 Socket screw. 35mm long Countersunk head.	10
F0930ZPK M8 Socket screw. 20mm long Button head.	10
F0931ZPK M8 Socket screw. 30mm long Button head.	10
F0935ZPK M12 Socket screw. 20mm long Button head.	10



C00215	J bolt (metric). M12 - 107mm long (replaces imperial bolt from July 2003).
C00216	J bolt (metric). M12 - 75mm long (replaces imperial bolt from July 2003).
P0015	Wheelnut cover. Black poly cap for M12 wheel nuts.
P00911	Nut cover. Black poly cap for M14 nuts.
C09804	M16 Studding. 115mm long - Now used in place of 5/8" in spare wheel installations.
C09803	M16 Studding. 165mm long - Now used in place of 5/8" in spare wheel installations.
F1089Z	M8 Wing nut. Multi purpose fastener found on many canopies.
F1091Z	M8 Spherical nut. M8 used at the compensator end of the brake cables.

For leaf spring and u bolt fasteners please see page 45